




Original	Sustituto
 Power	 Power
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0/AV	 AV / Input / RDS
 0/AV	 0
 Up	 Up
 P+	 CH+ / Page+
 Right	 Right
 Vol+	 Vol+
 Left	 Left

Original	Sustituto
 Vol-	 Vol-
 OK	 OK
 Down	 Down
 P-	 CH- / Page-
 i	 Info / Angle
 Format / Picture	 Picture / Format
 TXT	 Text / Goto
 Mute	 Mute / Dimmer
 Red/AKT	 Red / Netflix / Search
 Green/Timer	 Sleep / Timer
 Green/Timer	 Green / APP / Repeat
 Yellow/[I]	 Yellow / YouTube / Repeat
 Blue/[++]	 Blue / Prime Video / Random
 -O	 << / Tune-
 O+	 >> / Tune+
 -*	 I<< / Preset-
 *+	 >>I / Preset+



























Original		Sustituto		Original		Sustituto	
	PIP		Setup / OPT /				
	IDTV-?		Smart / List				
	P/C-ATS		Display / Media				
	AUX	+	Shift + 7				





Original	Sustituto	Original	Sustituto
	Power		Power
	P+		CH+ / Page+
	P-		CH- / Page-
	Rec		Rec / Rec Mode
	Play		Play / Slow
	Pause		Pause / Step / Freeze
	Stop		Stop / Hold
	<		Left
	>		Right
	<<		<< / Tune-
	>>		>> / Tune+





Original		Sustituto		Original		Sustituto	
	Power		Power		Vol-		Vol-
	1		1		OK		OK
	2		2		P-		CH- / Page-
	3		3		Down		Down
	4		4		i		Info / Angle
	5		5		Format / Picture		Picture / Format
	6		6		TXT		Text / Goto
	7		7		Mute		Mute / Dimmer
	8		8		Red/AKT		Red / Netflix / Search
	9		9		Green/Timer		Green / APP / Repeat
	0/AV		AV / Input / RDS		Green/Timer		Sleep / Timer
	0/AV		0		Yellow/[I]		Yellow / YouTube / Repeat
	P+		CH+ / Page+		Blue/[++]		Blue / Prime Video / Random
	Up		Up		-O		<< / Tune-
	Right		Right		O+		>> / Tune+
	Vol+		Vol+		-*		I<< / Preset-
	Left		Left		*+		>>I / Preset+





Original	Sustituto	Original	Sustituto
PIP	Setup / OPT /		
IDTV-?	Smart / List		
P/C-ATS	Display / Media		
AUX	+ 7 Shift + 7		

