



Original	Sustituto	Original	Sustituto
Power	Power	P+	Ch +
Source	AV	P-	Ch -
1	1	CH List	List
2	2	Smart Hub	Smart
3	3	Menu	Menu
4	4	Search	TV/R
5	5	Tools	Options
6	6	Info	Info
7	7	Return	Back
8	8	Exit	Exit
9	9	Up	Up
0	0	Down	Down
TTX/MIX	Text	Right	Right
PRE-CH	Pre Ch	Left	Left
Vol+	Vol +	Enter	Ok
Vol-	Vol -	Red	Red
Mute	Mute	Green	Green

Original	Sustituto	Original	Sustituto
P+	Ch +	CH List	List
P-	Ch -	Smart Hub	Smart
Menu	Menu	Search	TV/R
Tools	Options	Info	Info
Return	Back	Exit	Exit
Up	Up	Down	Down
Right	Right	Left	Left
Enter	Ok	Red	Red
Green	Green		





Original	Sustituto	Original	Sustituto
Yellow	Yellow		
Blue	Blue		
SOCIAL TV	APP MEDIA		
HDMI	AD SUBT		
3D	ECO 3D		
E-MANUAL	E-MANUAL D.MENU		
P.SIZE	PICTURE FORMAT		
SRS	SOUND DUAL		
<<	<<		
I<<	I<<		
Pause	Pause		
>>	>>		
>>I	>>I		
Rec	REC MODE		
Play	PLAY MODE		
Stop	Stop		

