
































Original	Sustituto
	
	
	
	
	
	
	
	
	
	
	
	
	
	
	
	
	

Original	Sustituto
	
	
	
	
	
	
	
	
	
	
	
	
	
	
	
	
	



























Original	Sustituto	Original	Sustituto
	Repeat		Text
	Surr.		Red
	Sound	 + 	Shift + Dual
	Vocal		Yellow
	Karaoke		Blue




























Original	Sustituto
 Power	 Power
 Tuner	 Media
 Display	 Info
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 I<<<	 I<<<
 Play	 Play
 >>>I	 >>>I
 Stop	 Stop
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute
 1	 1
 2	 2

Original	Sustituto
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Program	 Sleep
 Surr.	 Red
 Sound	 Dual







Original	Sustituto
 Power	 Power
 TV	 Media
 Setup	 Options
 Display	 Info
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 I<<	 I<<
 Play	 Play
 >>I	 >>I
 Stop	 Stop
 Tv Vol+	 Vol +
 Tv Vol-	 Vol -
 Mute	 Mute
 1	 1

Original	Sustituto
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Surr.	 Red
 Sound	 Dual





Original	Sustituto
	
AUX/DI	Media
Display	Info
Up	Up
Down	Down
Right	Right
Left	Left
OK	Ok
I<<	I<<
Play	Play
>>I	>>I
Stop	Stop
Vol+	Vol +
Vol-	Vol -
Mute	Mute
1	1
2	2

Original	Sustituto
	
4	4
5	5
6	6
7	7
8	8
9	9
0	0
Program	Sleep
Surr.	Red
Sound	Dual

