








































































Original	Sustituto
 Power	 Power
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 CH.List	 List
 Recall	 Pre Ch
 PIC.Mode	 Shift + Format
 S.Mode	 Shift + Dual
 Source	 AV

Original	Sustituto
 Vol+	 Vol +
 Vol-	 Vol -
 CH+	 Ch +
 CH-	 Ch -
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 Exit	 Exit
 Menu	 Menu
 Red/DVD Setup	 Red
 Green/Repeat	 Green
 Yellow/Languag	 Yellow
 Blue/DVD Menu	 Blue
 Title/Aspect	 3D
 Zoom/Tv/Radio	 TV/R





Original	Sustituto	Original	Sustituto
	Sleep		Sleep
	Subtitle		Subt
	Prog/Index		Shift + Sleep
	A-B/Reveal		Media
	Step/Audio		Dual
	Info/Display		Info
	Text		Text
	Size		Format
	Hold		Options
	Subpage		Guide
	Eject		Eject
	Play		Play
	Pause		Pause
	Stop		Stop
	I<<		I<<
	>>I		>>I
	<<		<<

