





























Original	Sustituto
 Power	 Power
 Mute	 Mute
 DVB/Analogue	 Smart
 AV	 AV
 Sleep	 Sleep
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 S.Effect	 Media
 ▼/O/I/II	 Shift + Dual

Original	Sustituto
 Vol+	 Vol +
 Vol-	 Vol -
 PR/Page+	 Ch +
 PR/Page-	 Ch -
 Up/[≡▲]	 Up
 Down/[≡▼]	 Down
 Right	 Right
 Left	 Left
 OK/Select	 Ok
 Guide	 Guide
 Subtitle	 Subt
 Language	 Dual
 Favourite	 Pre Ch
 Prev PR	 Back
 Menu	 Menu
 Aspect	 3D
 Normal	 Options





Original	Sustituto	Original	Sustituto
[i]/Recall	Info		
Cancel/Exit	Exit		
Red	Red		
Green	Green		
Yellow	Yellow		
Blue	Blue		
[=]/Text	Text		
[=?]/Reveal	TV/R		
[=x]/T.Cancel	Eject		
[=◇]/Size	Format		
[=o]/Subcode	D. Menu		
[=+]/Hold	Shift + TV/R		
[=i]/Index	List		
Game	Shift + Smart		

