







Original	Sustituto
Standby	Power
Off	Shift + Power
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
_/---/Del	GUIDE Guide
Mute	Mute
Vol+	Vol +
Vol-	Vol -
Content (Home)	HOME SMART Smart

Original	Sustituto
Source	AV AV
CH+	Ch +
CH-	Ch -
Magicinfo/Lite /S	MEDIA Media
Menu	Menu
Blank	PRE-CH Pre Ch
Tools	OPT Options
Info	INFO Info
Return	BACK Back
Exit	EXIT Exit
Up	Up
Down	Down
Right	Right
Left	Left
Enter	OK Ok
Red/PC	Red
Green/DVI	Green





Original		Sustituto		Original	Sustituto
	Yellow/HDMI		Yellow		
	Blue/DP		Blue		
	Magicinfo		TV/R		
	3D		3D		
	Lock		Eject		
	Stop		Stop		
	<</ <<		<<		
	Play		Play		
	Pause		Pause		
	>>/>>		>>		

