



Original	Sustituto	Original	Sustituto
	Power		Power
	Mute		Mute
	COMP		Smart
	HDMI		Media
	AV		AV
	TV		Shift + Media
	Source		Shift + AV
	Info		Info
	Menu		Menu
	Aspect		Format
	Still		Pause
	Exit		Exit
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	Audio		Dual
	TV / Radio		TV/R
	Sub		Subt
	Text		Text
	[≡?]		Shift + D. Menu
	[≡^v]		Play
	Mix		Options
	EPG		Guide
	Red / P.Mode		Red
	Green / S.Mode		Green
	Yellow / S.Effect		Yellow
	Blue / Stereo		Blue
	Vol +		Vol +
	Vol -		Vol -
	Back		Back
	CH +		Ch +
	CH -		Ch -





Original	Sustituto	Original	Sustituto
	1		Sleep
	2		Sleep
	3		
	4		
	5		
	6		
	7		
	8		
	9		
	0		
	Fav		
	Prev		
	PIP		
	P.Source		
	P.Size		
	Position		
	P.Swap		
	Shift + Pre Ch		
	Pre Ch		
	D. Menu		
	Eject		
	3D		
	List		
	Shift + Back		

