


































































Original	Sustituto
	 Power
	 +  Shift + Menu
	 AV
	 Dual
	 Subt
	 Info
	 D. Menu
	 TV/R
	 Eject
	 +  Shift + AV
	 Back
	 Options
	 Guide
	 Up
	 Down
	 Right
	 Left

Original	Sustituto
	 Red / Menu
	 +  Shift + Format
	 Green / Menu
	 +  Shift + Dual
	 Yellow / Other
	 Menu
	 Blue / OK
	 Blue / OK
	 +  Shift + Subt
	 Text
	 Ch -
	 Ch +
	 Vol -
	 Vol +
	 1
	 2
	 3







































































	Original	Sustituto	Original	Sustituto
	4			
	5			
	6			
	7			
	8			
	9			
	0			
	Mute			
	P < P			
	Format			
	Freeze			
	Smart Controls Picture			
	Smart Controls Audio			





Original	Sustituto	Original	Sustituto
	Power		Power
	Time		TV/R
	Zoom		3D
	Mix		Text
	[?]		Shift + Info
	[+]		Info
	Freeze/Rec		Pause
	Format/Stop		Format
	Source		AV
	I-II		Dual
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Rec		Rec
	<<		<<
	>>		>>
	Stop		Stop
	Play		Play
	Timer		Shift + AV
	P-		Ch -
	P+		Ch +
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	-/-		Guide

