







































































Original		Sustituto		Original		Sustituto	
	Power		Power		i		Info
	1		1		P+		Ch +
	2		2		P-		Ch -
	3		3		Up		Up
	4		4		Down		Down
	5		5		Right		Right
	6		6		Left		Left
	7		7		OK		Ok
	8		8		Vol+		Vol +
	9		9		Vol-		Vol -
	0/AV		0		Audio		Dual
	P/C/CL		Pre Ch		Blue		Blue
	Pause		Pause		Yellow		Yellow
	<<		<<		Green		Green
	Play		Play		Red/OTR		Red
	>>		>>		Next		>>I
	TXT		Text		Prev		I<<














































































Original	Sustituto	Original	Sustituto
	Power		Power
	Pause		Pause
	<<		<<
	Play		Play
	>>		>>
	i		Info
	Rec		Rec
	Stop		Stop
	P+		Ch +
	P-		Ch -
	Up		Up
	Down		Down
	☺+		Smart
	☹-		Media





Original	Sustituto	Original	Sustituto
 Power	 Power	 i	 DISPLAY INFO Info
 1	 1	 P+	 Up
 2	 2	 P-	 Down
 3	 3	 	 Right
 4	 4	 	 Left
 5	 5	 OK	 Ok
 6	 6	 P+	 + Ch +
 7	 7	 P-	 - Ch -
 8	 8	 	 Vol +
 9	 9	 	 Vol -
 0 AV	 0	 	 SOUND DUAL Dual
 P/C CL	 FAV PRE-CH Pre Ch	 NEXT Blue	 D Blue
 	 	 PREV. Yellow	 C Yellow
 	 	 Green	 B Green
 	 PLAY MODE Play	 OTR Red/OTR	 A Red
 	 	 NEXT Next	  >>I
 TXT	 REPEAT TEXT Text	 PREV. Prev	  I<<



