



Original	Sustituto	Original	Sustituto
 Power	 Power	 Menu	 Menu
 Home	 Smart	 FAV	 Pre Ch
 Mute	 Mute	 TXT	 Text
 Red/Shift	 Red	 SAT	 Media
 Green/USB	 Green	 Back	 Back
 Yellow	 Yellow	 Find	 TV/R
 Blue/TV-Radio	 Blue	 CH+	 Ch +
 1	 1	 CH-	 Ch -
 2	 2	 Up	 Up
 3	 3	 Down	 Down
 4	 4	 Right	 Right
 5	 5	 Left	 Left
 6	 6	 OK	 Ok
 7	 7	 Vol+	 Vol +
 8	 8	 Vol-	 Vol -
 9	 9	 i	 Info
 0	 0	 EPG	 Guide



