





















	Original	Sustituto	Original	Sustituto
	Power			>>I
	Source			<<
	Open/Close			>>
	Sleep			Stop
	1			Play
	2			Pause
	3			Vol +
	4			Vol -
	5			Mute
	6			Repeat
	7			Tuning+
	8			Tuning-
	9			Disc Menu
	0			Menu
	Dolby PL			Title Menu
	DSP/EQ			Tools
	I<<			Info
				Info







































Original	Sustituto
 Return	 Back
 Exit	 Exit
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 Enter	 Ok
 Red	 Red
 Green/Tuner	 Green
 Yellow/MO/ST	 Yellow
 Blue/CD Ripping	 Blue
 Dimmer	 Subt
 S.Vol	 Format
 P.Bass/Audio Upscale	 3D

Original	Sustituto







Original	Sustituto
 Power	 Power
 Function Tv	 AV
 Sleep	 Sleep
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 <<	 <<
 >>	 >>
 Stop	 Stop
 Play	 Play

Original	Sustituto
 Pause	 Pause
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute
 CH+	 Ch +
 CH-	 Ch -
 Menu	 Menu
 Tools	 Options
 Info	 Info
 Return	 Back
 Exit	 Exit
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 Enter	 Ok
 Red	 Red





	Original	Sustituto	Original	Sustituto
TUNER MEMORY B	Green	B	Green	
MO/ST C	Yellow	C	Yellow	
CD RIPPING D	Blue	D	Blue	

