



Original	Sustituto
Power	Power
EPG	Guide / EPG / -/--
Teletext	Text / Goto
Select	Smart / List
Confirm	D.Menu / Top
Title	Sound / Title
Eject	Eject / Surround
Menu	Menu / Home
Option	Shift + Setup / OPT / Tools
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8

Original	Sustituto
9	9
Zoom	Zoom / Size
0	0
Goto	Shift + Text /
i/Display	Display / Media
Guide	Shift + Guide / EPG / -/--
Up	Up
Left	Left
OK	OK
Right	Right
Rec	Rec / Rec Mode
Down	Down
Return	Back / Return
Vol-	Vol-
Vol+	Vol+
<<	<< / Tune-
Stop	Stop / Hold





	Original	Sustituto
	Play	Play / Slow
	>>	>> / Tune+
	I<<	I<< / Preset-
	I>/Slow	Info / Angle
	Pasue/Step	Pause / Step / Freeze
	>>I	>>I / Preset+
	Source	AV / Input / RDS
	Time Shift	Picture / Format
	Repeat	+  Shift + Green / APP /
	aA/Subtitle	Subtitle / EQ
	Setup	Setup / OPT /
	Red	Red / Netflix / Search
	Tv System	TV/Radio /
	Green	Green / APP / Repeat
	Audio	Audio / Lang I/II
	Yellow	Yellow / YouTube / Repeat
	Mute	Mute / Dimmer

	Original	Sustituto
	Blue	Blue / Prime Video / Random

