



| Original  | Sustituto       | Original  | Sustituto       |
|---|-----------------|---|-----------------|
|      | POWER           |      | Power           |
|      | SCREEN SIZE     |      | 3D              |
|      | AUTO SET UP     |      | Options         |
|      | MUTE            |      | Mute            |
|      | ZOOM            |      | Eject           |
|      | PC 1            |      | Shift + 1       |
|      | PC 2            |      | Shift + 2       |
|      | DISPLAY         |      | Info            |
|      | TV              |      | TV/R            |
|      | SCART           |      | AV              |
|     | DVI             |     | Shift + 3       |
|    | PLASMA MENU     |    | D. Menu         |
|    | PLASMA MENU     |    | Shift + D. Menu |
|    | UP / CH +       |    | Up              |
|    | UP / CH +       |    | Ch +            |
|    | DOWN / CH -     |    | Down            |
|    | DOWN / CH -     |    | Ch -            |
|    | RIGHT           |    | Right           |
|    | LEFT            |    | Left            |
|    | SET             |    | Ok              |
|    | VOL +           |    | Vol +           |
|    | VOL -           |    | Vol -           |
|    | MENU TV         |    | Menu            |
|    | PIP ON / OFF TV |    | Media           |
|    | PIP SWAP TV     |    | I<<             |
|    | PIP MOVE TV     |    | >>I             |
|    | PIP TYPE TV     |    | Shift + Media   |
|   | AUDIO TV        |   | Dual            |
|  | CLOCK TV        |  | Sleep           |
|  | 1 TV            |  | 1               |
|  | 2 TV            |  | 2               |
|  | 3 TV            |  | 3               |
|  | 4 TV            |  | 4               |
|  | 5 TV            |  | 5               |





| Original  | Sustituto   | Original | Sustituto |
|---|---|----------|-----------|
|  6 TV            |  6             |          |           |
|  7 TV            |  7             |          |           |
|  8 TV            |  8             |          |           |
|  9 TV            |  9             |          |           |
|  0 TV            |  0             |          |           |
|  TV / TEXT / MIX |  Text          |          |           |
|  LIST TV         |  Smart         |          |           |
|  ZOOM TV         |  Shift + Eject |          |           |
|  HOLD TV         |  Stop          |          |           |
|  REVEAL TV       |  Format        |          |           |
|  INDEX TV       |  Pause        |          |           |
|  EXPAND TV     |  Exit        |          |           |
|  RED TV        |  Red         |          |           |
|  GREEN TV      |  Green       |          |           |
|  YELLOW TV     |  Yellow      |          |           |
|  BLUE TV /     |  Blue        |          |           |
|  BLUE TV /     |  Subt        |          |           |



SUBTITLES