



Original	Sustituto	Original	Sustituto
	Power		Power
	Input		AV
	TV/TXT		Text
	Cancel		Media
	Reveal		D. Menu
	Nicam/A2		Dual
	Size		Format
	Hold		Eject
	Index		TV/R
	Subpage		Options
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	CH+		Ch +
	CH-		Ch -
	Mute		Mute
	Menu		Menu
	Exit		Exit
	Vol+		Vol +
	Vol-		Vol -
	Channel List		Smart
	EPG		Guide
	Info		Info
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	1		1
	2		2
	3		3
	4		4
	5		5





Original	Sustituto
6	6
7	7
8	8
9	9
0	0
FAV	PRE-CH
Recall	BACK
Picture	SHIFT + PICTURE FORMAT
Sound	SHIFT + SOUND DUAL
Sleep	PROG SLEEP
Subtitle	AD SUBT
Rec	REC MODE
Aspect	ECO 3D
<<	<<
>>	>>
<<	⏪
>>	⏩

Original	Sustituto
Play	PLAY MODE
Pause	⏸
Stop	⏹
List	DISC NAV LIST
Repeat	SHIFT + REPEAT TEXT

