






Original	Sustituto
	 Power
	 1
	 2
	 3
	 4
	 5
	 6
	 7
	 8
	 9
	 ? / Audio
	 0
	 Aspect / Subtitle
	 Aspect / Subtitle
	 PIP / Recall
	 AV
	 Mute

Original	Sustituto
	 Info / Angle
	 Up / P+
	 Up / P+
	 Z / Return
	 Left / Vol -
	 Left / Vol -
	 OK
	 Right / Vol +
	 Right / Vol +
	 MENU / Home
	 TXT / Menu
	 Down / P-
	 Down / P-
	 TV-G / Top
	 Red / Rec
	 Red / Rec
	 Green / Play



