



Original	Sustituto
 Standby	 Power
 Open / Close	 Eject
 Mute	 Mute
 OSD	 Smart
 Step	 Shift + Pause
 Recover	 Media
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 +10	 Guide

Original	Sustituto
 Clear	 Exit
 Setup	 Options
 Search	 TV/R
 Up	 Up
 Right	 Right
 Down	 Down
 Left	 Left
 Enter	 Ok
 Subtitle	 Subt
 Audio	 Dual
 Play	 Play
 Pause	 Pause
 Stop	 Stop
 I<<	 I<<
 >>I	 >>I
 <<	 <<
 >>	 >>





Original

Sustituto

	Angle		Format
	Zoom		Shift + Eject
	3D		3D
	Prog		Sleep
	Title		Info
	Repeat		Text
	A-B		Shift + Text
	Slow		Shift + Play
	Menu		Menu
	N/P		List
	Vol -		Vol -
	Vol +		Vol +
	PS		Yellow
	Audio Up		Shift + Dual

Original

Sustituto


