



Original	Sustituto
	Power
	Media
	Smart
	TV/R
	Vol +
	Vol -
	Mute
	Back
	>>I
	I<<
	Exit
	Menu
	Up
	Down
	Right
	Left
	Ok

Original	Sustituto
	Red
	Green
	Yellow
	Blue
	Pre Ch
	1
	2
	3
	4
	5
	6
	7
	8
	9
	0
	AV
	Shift + Play





	Original	Sustituto		
	<<		<<	
	Play		Play	
	>>		>>	
	Record		Rec	
	Stop		Stop	
	Pause		Pause	
	Again/SP/LP		Options	
	Zoom/Index		Info	
	Open/Close		Eject	

	Original	Sustituto		






Original	Sustituto
	Power
	Media
	Smart
	TV/R
	Vol +
	Vol -
	Mute
	Back
	Ch +
	Ch -
	Exit
	Menu
	Up
	Down
	Right
	Left
	Ok

Original	Sustituto
	Red
	Green
	Yellow
	Blue
	Pre Ch
	1
	2
	3
	4
	5
	6
	7
	8
	9
	0
	AV
	Shift + Play





	Original	Sustituto	
	<<		<<
	Play		Play
	>>		>>
	Record		Rec
	Stop		Stop
	Pause		Pause
	Again/SP/LP		Options
	Zoom/Index		Info
	Open/Close		Eject

	Original	Sustituto






Original	Sustituto
	Power
	Media
	Smart
	TV/R
	Vol +
	Vol -
	Mute
	Back
	Ch +
	Ch -
	Exit
	Menu
	Up
	Down
	Right
	Left
	Ok

Original	Sustituto
	Red
	Green
	Yellow
	Blue
	Pre Ch
	1
	2
	3
	4
	5
	6
	7
	8
	9
	0
	AV
	<<





Original	Sustituto	Original	Sustituto
	Play		Play
	>>		>>
	Record		Rec
	Stop		Stop
	Pause		Pause

Original	Sustituto

