















Original	Sustituto	Original	Sustituto
	Power		Power
	Mute		Mute
	Audio		Dual
	TV / STB		Shift + TV/R
	TV / R		TV/R
	Sleep		Sleep
	SUB		Subt
	TXT		Text
	P / N		Shift + 1
	Recall		Pre Ch
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	PGUP		Vol +
	PGDN		Vol -
	SAT		Shift + AV
	FAV +		Ch +
	FAV -		Ch -
	EPG		Guide
	Fav		Shift + Pre Ch
	Up		Up
	Right		Right
	Down		Down
	Left		Left
	OK		Ok
	Menu		Menu
	Exit		Exit





Original	Sustituto
	 Red
	 Green
	 Yellow
	 Blue
	 Pause
	 Eject
	 Format
	 Info
	 AV
	 Media
	 Smart
	 List
	 Back
	 Shift + 2
	 Options
	 Stop
	 Rec

Original	Sustituto
	 <<<
	 >>>
	 Play
	 Shift + Pause
	 I<<<
	 >>>I

