



Original	Sustituto
Power	Power
DTV / ATV	Smart
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
- / -	+  Shift + Guide
Recall	Back
P.Mode	+  Shift + Format
S.Mode	Dual
Aspect	Format

Original	Sustituto
Still	Pause
P -	Ch -
P +	Ch +
V -	Vol -
V +	Vol +
Sleep	Sleep
Mute	Mute
MTS	+  Shift + Media
Menu	Menu
Source	AV
Up	Up
Right	Right
Down	Down
Left	Left
Enter	Ok
Exit	Exit
i	Info





Original	Sustituto	Original	Sustituto
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	Text / <<		Text
	Text / <<		<<
	Hold / >>		>>
	Hold / >>		Shift + Pause
	Mix / I<<		I<<
	Mix / I<<		Shift + Text
	Timer / >>I		>>I
	[≡] / Play/Pause		Play
	[≡] / Play/Pause		Shift + Info
	Size / Stop		Stop
	Size / Stop		Eject
	[ ? ]		D. Menu
	Subtitle		Subt

