



Original	Sustituto
 Power	 Power
 Mute	 Mute / Dimmer
 Audio	 Audio / Lang I/II
 TV / STB	 AV / Input / RDS
 TV / R	 TV/Radio /
 Sleep	 Sleep / Timer
 SUB	 Subtitle / EQ
 TXT	 Text / Goto
 Multi	 Display / Media
 P / N	 Picture / Format
 Recall	 Back / Return
 1	 1
 2	 2
 3	 3
 4	 4
5	5
6	6

Original	Sustituto
 7	 7
 8	 8
 9	 9
 0	 0
 SAT	 Shift + 0
 EPG	 Guide / EPG / -/-
 Fav	 Fav / Marker / PC
 PGUP	 CH+ / Page+
 PGDN	 CH- / Page-
 Up	 Up
 Right	 Right
 FAV +	 Vol+
 FAV -	 Vol-
 Down	 Down
 Left	 Left
OK	OK
Menu	Menu / Home





Original	Sustituto
	Exit / Cancel / Clear
	Red / Netflix / Search
	Green / APP / Repeat
	Yellow / YouTube / Repeat
	Blue / Prime Video / Random
	Pause / Step / Freeze
	Zoom / Size
	D.Menu / Top
	Info / Angle
	Shift + 8
	Shift + Yellow / YouTube /
	Shift + Text /
	Shift + 1
	Shift + 2
	Eject / Surround
	Stop / Hold
	Rec / Rec Mode

Original	Sustituto
	Sound / Title
	<< / Tune-
	>> / Tune+
	Smart / List
	Play / Slow
	I<< / Preset-
	Setup / OPT /
	>>I / Preset+

