



Original	Sustituto
Standby	Power
Source	AV
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
Recall	Back
FAV	Pre Ch
P.Mode	Format
S.Mode	Shift + Dual
Sleep	Sleep

Original	Sustituto
Tv/Radio	TV/R
Display	Info
Menu	Menu
Exit	Exit
Up	Up
Down	Down
Right	Right
Left	Left
OK	Ok
Vol+	Vol +
Vol-	Vol -
Mute	Mute
Guide	Guide
Media	Media
CH+	Ch +
CH-	Ch -
Rec	Rec





Original		Sustituto		Original		Sustituto	
	T.Shift		Options		Green		Green
	I/II/Audio		Dual		Yellow		Yellow
	Size/Aspect		3D		Blue		Blue
	Text		Text				
	Reveal		Smart				
	Hold		D. Menu				
	Subpage		Eject				
	Play		Play				
	Pause		Pause				
	Stop		Stop				
	<<		<<				
	>>		>>				
	I<<		I<<				
	>>I/Mix		>>I				
	Index/Reclist		List				
	Subtitle		Subt				
	Red		Red				

