













































| Original  | Sustituto |
|---|-----------|
|    | Power     |
|    | Mute      |
|    | 1         |
|    | 2         |
|    | 3         |
|    | 4         |
|    | 5         |
|    | 6         |
|    | 7         |
|    | 8         |
|   | 9         |
|  | Source    |
|  | 0         |
|  | Info      |
|  | DMP       |
|  | Up        |
|  | EPG       |


| Original  | Sustituto |
|---|-----------|
|    | Left      |
|    | Enter     |
|    | Right     |
|    | Menu      |
|    | Down      |
|    | Exit      |
|    | Vol +     |
|    | List      |
|    | CH +      |
|    | Vol -     |
|   | CH -      |
|  | Fav       |
|  | Sleep     |
|  | Index     |
|  | Recall    |
|  | Red / <<  |
|  | Red / <<  |







| Original  | Sustituto   | Original  | Sustituto          |
|---|-------------|---|--------------------|
|    | Power       |    | Power              |
|    | Mute        |    | Mute / Dimmer      |
|    | 1           |    | 1                  |
|    | 2           |    | 2                  |
|    | 3           |    | 3                  |
|    | 4           |    | 4                  |
|    | 5           |    | 5                  |
|    | 6           |    | 6                  |
|    | 7           |    | 7                  |
|   | 8           |   | 8                  |
|  | 9           |  | 9                  |
|  | [≡?]/Source |  | AV / Input / RDS   |
|  | 0           |  | 0                  |
|  | [≡i]/Info   |  | Info / Angle       |
|  | DMP         |  | D.Menu / Top       |
|  | Up          |  | Up                 |
|  | EPG         |  | Guide / EPG / -/-- |

| Original  | Sustituto | Original  | Sustituto              |
|---|-----------|---|------------------------|
|    | Left      |    | Left                   |
|    | Enter     |    | OK                     |
|    | Right     |    | Right                  |
|    | Menu      |    | Menu / Home            |
|    | Down      |    | Down                   |
|    | Exit      |    | Exit / Cancel / Clear  |
|    | Vol+      |    | Vol+                   |
|    | List      |    | Smart / List           |
|    | CH+       |    | CH+ / Page+            |
|   | Vol-      |   | Vol-                   |
|  | CH-       |  | CH- / Page-            |
|  | ♥         |  | Fav / Marker / PC      |
|  | Sleep     |  | Sleep / Timer          |
|  | Index     |  | Display / Media        |
|  | Back      |  | Back / Return          |
|  | Red       |  | Red / Netflix / Search |
|  | <<        |  | << / Tune-             |



