



Original	Sustituto
 Power	 Power
 Home	 Shift + Menu /
 1 / Add / Red	 1
 1 / Add / Red	 Red / Netflix / Search
 2 / Eject / Green	 Green / APP / Repeat
 2 / Eject / Green	 Eject / Surround
 2 / Eject / Green	 2
 3 / Delete / Yellow	 3
 3 / Delete / Yellow	 Yellow / YouTube / Repeat
 4 / Zoom	 4
 4 / Zoom	 Zoom / Size
 5 / Goto / Blue	 Blue / Prime Video / Random
 5 / Goto / Blue	 5
 5 / Goto / Blue	 Text / Goto
 6 / Menu	 Menu / Home
 6 / Menu	 6
 7 / Setup	 7

Original	Sustituto
 7 / Setup	 Setup / OPT /
 8 / Func	 8
 9 / TV Out	 TV/Radio /
 9 / TV Out	 9
 Info	 Info / Angle
 0 / Preview	 0
 Return	 Back / Return
 Up	 Up
 Left	 Left
 Enter	 OK
 Right	 Right
 Down	 Down
 I<< / PGUP	 I<< / Preset-
 Play / Pause	 Play / Slow
 Play / Pause	 Pause / Step / Freeze
 Stop	 Stop / Hold
 >>I / PGDN	 >>I / Preset+





Original	Sustituto
	TUNE- << / Tune-
	TUNE+ >> / Tune+
	VOL+ Vol+
	LANG I/II Audio / Lang I/II
	SHIFT + YouTube Shift + Yellow / YouTube /
	VOL- Vol-
	TITLE SOUND Sound / Title
	SHIFT + APP Shift + Green / APP /
	DIMMER MUTE Mute / Dimmer
	EQ SUBTITLE Subtitle / EQ
	CH PAGE CH- / Page-
	CH PAGE CH+ / Page+

Original	Sustituto

