

















Original	Sustituto
	 Power
	 Smart
	 1
	 2
	 3
	 4
	 5
	 6
	 7
	 8
	 9
	 0
	 Subt
	 Dual
	 D. Menu
	 Menu
	 Back



Original	Sustituto
	 Options
	 Up
	 Down
	 Right
	 Left
	 Ok
	 Stop
	 Play
	 Pause
	 Eject
	 I<<
	 <<
	 >>
	 >>I
	 Red
	 Green
	 Yellow





Original

Sustituto

Original	Sustituto
 Blue	 Blue

Original

Sustituto

Original	Sustituto

