







































































| Original | | Sustituto | | Original | | Sustituto | |
|---|---------|---|------------------|---|-----------|---|--------------------------|
|  | Power |  | Power |  | Vol + |  | Vol+ |
|  | Mute |  | Mute / Dimmer |  | Audio |  | Audio / Lang I/II |
|  | 1 |  | 1 |  | CH + |  | CH+ / Page+ |
|  | 2 |  | 2 |  | Vol - |  | Vol- |
|  | 3 |  | 3 |  | Aspect |  | Shift + Picture / Format |
|  | 4 |  | 4 |  | CH - |  | CH- / Page- |
|  | 5 |  | 5 |  | EPG / Set |  | Guide / EPG / -/- |
|  | 6 |  | 6 |  | Home |  | Shift + Menu / |
|  | 7 |  | 7 |  | APP |  | Shift + Green / APP / |
|  | 8 |  | 8 |  | Menu |  | Menu / Home |
|  | 9 |  | 9 |  | Up |  | Up |
|  | List |  | Smart / List |  | Source |  | AV / Input / RDS |
|  | 0 |  | 0 |  | Left |  | Left |
|  | Recall |  | Back / Return |  | Enter |  | OK |
|  | Picture |  | Picture / Format |  | Right |  | Right |
|  | Sound |  | Sound / Title |  | Exit |  | Exit / Cancel / Clear |
|  | Sleep |  | Sleep / Timer |  | Down |  | Down |





| Original | | Sustituto | | Original | | Sustituto | |
|----------|--------------|-----------|-----------------------------|----------|----------------|-----------|----------------|
| | Info | | Info / Angle | | Hold / Refresh | + | Shift + Stop / |
| | Red | | Red / Netflix / Search | | | | |
| | Green | | Green / APP / Repeat | | | | |
| | Yellow | | Yellow / YouTube / Repeat | | | | |
| | Blue | | Blue / Prime Video / Random | | | | |
| | << / Index | | << / Tune- | | | | |
| | Play/Pause / | | Play / Slow | | | | |
| | >> / TTX | | Text / Goto | | | | |
| | >> / TTX | | >> / Tune+ | | | | |
| | I<< / Sub.Pg | | I<< / Preset- | | | | |
| | >>I / Reveal | | >>I / Preset+ | | | | |
| | Stop / Mix | | Stop / Hold | | | | |
| | Capture | | Display / Media | | | | |
| | Subtitle | | Subtitle / EQ | | | | |
| | Freeze | | Pause / Step / Freeze | | | | |
| | FAV | | Fav / Marker / PC | | | | |
| | Size / Mouse | | Zoom / Size | | | | |

