





Original	Sustituto
	
Mute	MUTE
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
[≡]	REPEAT TEXT
←	RETURN BACK
MENU	TOP MENU MENU
EXIT	CLEAR EXIT
Up	Up

Original	Sustituto
	
OK	OK
	
	
Red	A
Green	B
Yellow	C
Blue	D
VOL+	+ VOL
VOL-	VOL -
EPG	- / - GUIDE
00:00	TIMER AV
CH+	+ CH
CH-	CH -
[◀▶]	ECO 3D
[_]	AD SUBT
Lang	SOUND DUAL





Original	Sustituto
□ / ♪	SEARCH TV/R TV/R
♥	FAV PRE-CH Pre Ch
(i)	DISPLAY INFO Info

Original	Sustituto

