

































Original		Sustituto		Original		Sustituto	
	Power		Power				
	Bluetooth		9				
	Source		AV / Input / RDS				
	Vol+		Vol+				
	Vol-		Vol-				
	Mute		Mute / Dimmer				
	>>		>> / Preset+				
	<<		<< / Preset-				
	Play/Pause		Play / Slow				
	Play/Pause		Pause / Step / Freeze				
	Bass+		Right				
	Bass-		Left				
	EQ		Subtitle / EQ				
	Tre+		Up				
	Tre-		Down				





Original	Sustituto	Original	Sustituto
Power		Power	Power
Optical		1	1
Optical		Red / Netflix / Search	Red / Netflix / Search
Mute		Mute / Dimmer	Mute / Dimmer
AUX		7	7
AUX		Green / APP / Repeat	Green / APP / Repeat
BT		9	9
BT		Yellow / YouTube / Repeat	Yellow / YouTube / Repeat
HDMI ARC		0	0
HDMI ARC		Blue / Prime Video / Random	Blue / Prime Video / Random
Vol+		Vol+	Vol+
Vol+		Up	Up
I<		I<< / Preset-	I<< / Preset-
I<		Left	Left
Play/Pause / Pair		OK	OK
Play/Pause / Pair		Play / Slow	Play / Slow
Play/Pause / Pair		Pause / Step / Freeze	Pause / Step / Freeze

Original	Sustituto	Original	Sustituto
>I		>>I / Preset+	>>I / Preset+
>I		Right	Right
Vol-		Vol-	Vol-
Vol-		Down	Down
News		Audio / Lang I/II	Audio / Lang I/II
Movie		Picture / Format	Picture / Format
Music		Sound / Title	Sound / Title

