





















































Original		Sustituto		Original		Sustituto	
	Power		Power		Vol -		Vol -
	TV / Radio		TV/R		PG+		Ch +
	Mute		Mute		PG-		Ch -
	i		Info		1		1
	ALT		Back		2		2
	M/A		Smart		3		3
	Teletext		Text		4		4
	Exit		Exit		5		5
	Menu		Menu		6		6
	FAV		Pre Ch		7		7
	P/L		Media		8		8
	Up		Up		9		9
	Left		Left		0		0
	OK		Ok				
	Right		Right				
	Down		Down				
	Vol +		Vol +				

