







































































Original	Sustituto	Original	Sustituto
 Power	 Power	 Up	 Up
 [≡i]/Info	 Info	 Down	 Down
 Mute	 Mute	 Right	 Right
 1	 1	 Left	 Left
 2	 2	 Enter	 Ok
 3	 3	 CH+	 Ch +
 4	 4	 CH-	 Ch -
 5	 5	 Index	 Smart
 6	 6	 List	 List
 7	 7	 Vol+	 Vol +
 8	 8	 Vol-	 Vol -
 9	 9	 ♥	 Pre Ch
 0	 0	 Sleep	 Sleep
 [≡?]/Source	 AV	 EPG	 Guide
 (OI/II/Audio	 Dual	 Back	 Back
 Menu	 Menu	 Red	 Red
 Exit	 Exit	 Green	 Green



