
























Original	Sustituto
 Power	 Power
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute
 Return	 Back
 PR+	 Ch +
 PR-	 Ch -
 Menu	 Menu
 Exit	 Exit
 Up	 Up
 OK	 Ok
 Down	 Down
 Right	 Right
 Left	 Left
 Red	 Red
 Presets	 Dual
 Green	 Green


Original	Sustituto
 Yellow	 Yellow
 Info	 Info
 Blue	 Blue
 Violet	 Media
 Text	 Text
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0/--	 0
 AV	 AV
 Stop	 Stop
























Original	Sustituto	Original	Sustituto
RLC	Rec		Rec
	Pause		Pause
	Play		Play
	<<		<<
	>>		>>
	ZZZ/List		List
	Guide		Guide
	Zoom+		>>
	Zoom-		<<
























Original	Sustituto
 Power	 Power
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute
 Return	 Back
 PR+	 Ch +
 PR-	 Ch -
 Menu	 Menu
 Exit	 Exit
 OK	 Ok
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 Red	 Red
 Presets	 Dual
 Green	 Green


Original	Sustituto
 Info	 Info
 Yellow	 Yellow
 Blue	 Blue
 Violet	 Media
 Text	 Text
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0/--	 0
 AV	 AV
 Play	 Play


























Original		Sustituto		Original		Sustituto	
	Stop		Stop				
	Pause		Pause				
	Rec		Rec				
	<<		<<				
	>>		>>				
	Zoom+		>>				
	Zoom-		<<				
	ZZZ/List		List				
	Guide		Guide				






Original	Sustituto
 Power	 Power
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute
 PR+	 Ch +
 PR-	 Ch -
 Return	 Back
 Exit	 Exit
 Menu	 Menu
 OK	 Ok
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 Red	 Red
 Presets	 Dual
 Green	 Green

Original	Sustituto
 Info	 Info
 Yellow	 Yellow
 Blue	 Blue
 Violet	 Media
 Text	 Text
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0/--	 0
 AV	 AV
 Rec	 Rec





Original

Sustituto

	Stop		Stop
	Pause		Pause
	Play		Play
	<<		<<
	>>		>>
	Zoom+		>>I
	Zoom-		I<<
	ZZZ/List		List
	Guide		Guide

Original

Sustituto

