







































































Original	Sustituto
 Power	 Power
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 i	 Info
 AV	 AV
 Red	 Red
 Green	 Green
 Yellow	 Yellow

Original	Sustituto
 Blue	 Blue
 TV / DTV	 Smart
 Menu	 Menu
 Up	 Up
 Left	 Left
 OK	 Ok
 Right	 Right
 Down	 Down
 Guide	 Guide
 Back	 Back
 P-	 Ch -
 P+	 Ch +
 Vol+	 Vol +
 Vol-	 Vol -
 I/II	 Dual
 OO	 Shift + Dual
 TV / Radio	 TV/R





































Original		Sustituto	
	Colour System		Options
	Sleep Timer		Sleep
	[...]		Subt
	Zoom		Eject
	[≡]		Text
	[≡i]		List
	[?]		D. Menu
	[↓]		Format
	[⊖]		Shift + Subt

Original		Sustituto	





	Original	Sustituto	Original	Sustituto
	Power	 Power		
	Menu	 Menu		
	Back	 Back		
	OK	 Ok		
	Up	 Up		
	Down	 Down		
	Right	 Right		
	Left	 Left		
	<<	 <<		
	Play	 Play		
	>>	 >>		
	Stop	 Stop		
	Pause	 Pause		
	Rec / Top Menu	 Rec		
	↑	 Ch +		
	↓	 Ch -		





	Original	Sustituto		Original	Sustituto
	Power		Power		
	<<		<<		
	Play		Play		
	>>		>>		
	Rec		Rec		
	Pause		Pause		
	Stop		Stop		
	Up		Ch +		
	Down		Ch -		

