



Original	Sustituto
Standby/On	Power
Rec	Rec
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
Status/Exit	Exit
Clear	Shift + Exit
Play	Play
Stop	Stop
Up	Up

Original	Sustituto
Down	Down
Right	Right
Left	Left
>>	>>
<<	<<
Menu	Menu
Vol+	Vol +
Vol-	Vol -
> </Still	Pause
P+	Ch +
P-	Ch -
Mute	Mute
> /Index	Text
Slow	AV
System	Media
Turbo Timer	Options
SVV+	Format



