



Original	Sustituto
Power	Power
iPod	1
CD	2
USB	3
FM	4
Phono	5
AUX	6
Preset Up	Ch +
Preset Down	Ch -
Tuning Up	>>
Tuning Down	<<
Memory	Rec
Repeat	Text
Stop	Stop
Random	Media
iPod Menu Sel Up	Up
iPod Menu Sel Down	Down

Original	Sustituto
Menu	Menu
Play	Play
Pause	Pause
>>	>>
<<	<<
Enter	Ok
Vol+	Vol +
Vol-	Vol -
Mute	Mute
Tone/Balance	Right
Tone/Balance	Left
Tone/Balance	Smart
Display	Info
Dimmer	Subt
Sleep	Sleep
Pure Direct	Options



Down