







































































Original	Sustituto	Original	Sustituto
	Power		Power
	Mute		Mute
	Movie		1
	Music		2
	Photo		3
	Home		Smart
	Disk		Menu
	All Media		Media
	Subtitle		Subt
	Audio		Dual
	Zoom		Eject
	Info		Info
	Copy Target		Pre Ch
	Vol+		Vol +
	Vol-		Vol -
	P+		Ch +
	P-		Ch -
	OK		Ok
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Stop		Stop
	Pause		Pause
	<<		<<
	>>		>>
	I<<		I<<
	>>I		>>I
	Repeat		Text
	Tv Out		TV/R
	Setup		Options
	A-B		D. Menu
	BGM/Go to		Format
	Slide Type		Guide

