







































Original	Sustituto
 Standby	 Power
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Options	 Options
 EPG	 Guide
 Info	 Info
 FAV	 Pre Ch
 Menu	 Menu

Original	Sustituto
 Exit	 Exit
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 V+	 Vol +
 V-	 Vol -
 P+	 Ch +
 P-	 Ch -
 Page+	 >>
 Page-	 <<
 SAT	 Media
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue/Recall	 Blue





Original	Sustituto
Text	Text
Tv/Radio	TV/R
Subt	Subt
STB/TV	Smart
V.Format	Format

Original	Sustituto

