

































| Original | Sustituto | Original | Sustituto |
|--|---|--|---|
|  Power |  Power |  Delay Time > |  Up |
|  Phono |  1 |  << Tape |  << |
|  AUX 1 |  3 |  >> Tape |  >> |
|  Tape 1 |  4 |  Rec Tape |  Rec |
|  Tape 2 |  5 |  Stop Tape |  Stop |
|  Band |  Smart |  Pause Tape |  Pause |
|  A Tun |  Ok |  Play Tape |  Play |
|  < Tuning |  Left | | |
|  Tuning > |  Right | | |
|  Vol- |  Vol - | | |
|  Vol+ |  Vol + | | |
|  On screen |  Info | | |
|  CTR ECS |  List | | |
|  < SRND Mode |  Ch - | | |
|  SRND Mode > |  Ch + | | |
|  BAL CHK |  Dual | | |
|  < Delay Time |  Down | | |











| Original | Sustituto | Original | Sustituto |
|---|---|--|---|
|  Power |  Power |  SRND Mode > |  Ch + |
|  Vol+ |  Vol + |  BAL CHK |  Dual |
|  Vol- |  Vol - |  Delay Time > |  Up |
|  Phono |  1 |  < Delay Time |  Down |
|  AUX1 |  2 |  Pause Tape |  Pause |
|  AUX 2 |  3 |  Play Tape |  Play |
|  Tape 1 |  4 |  Stop Tape |  Stop |
|  Tape 2 |  5 |  >> Tape |  >> |
|  Video 1 |  6 |  Rec/Zone |  Options |
|  Video 2 |  7 |  << Tape |  << |
|  Video 3 |  8 |  Band |  Smart |
|  Off |  Exit |  Rec Tape |  Rec |
|  A Tun |  Ok |  On Screen |  Info |
|  Tuning > |  Right |  Tuner |  Media |
|  < Tuning |  Left | | |
|  CTR ECS |  List | | |
|  < SRND Mode |  Ch - | | |





| Original | Sustituto |
|--|--|
|  Power |  Power |
|  Band |  Smart |
|  A Tun |  Ok |
|  < Tuning |  Left |
|  Tuning > |  Right |
|  Vol- |  Vol - |
|  Vol+ |  Vol + |
|  On Screen |  Info |
|  CTR ECS |  List |
|  < SRND Mode |  Ch - |
|  SRND Mode > |  Ch + |
|  BAL CHK |  Dual |
|  < Delay Time |  Down |
|  Delay Time > |  Up |
|  << Tape |  << |
|  >> Tape |  Blue |
|  Rec Tape |  Rec |

| Original | Sustituto |
|--|---|
|  Stop Tape |  Stop |
|  Pause Tape |  Pause |
|  Play Tape |  Play |

