







































































Original	Sustituto	Original	Sustituto
	Power		Power
	Mute		Mute
	Function		Smart
	Input		AV
	Sleep		Sleep
	Return		Back
	EQ		Red
	VSM		Green
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Setup		Options
	Display		Info
	Up / Preset+		Up
	Down / Preset-		Down
	Right / Tun+		Right
	Left / Tun-		Left
	Enter		Ok
	Menu		Menu
	Title		3D
	<< / Scan-		<<
	>> / Scan+		>>
	Play		Play
	I<< / Skip-		I<<
	>>I / Skip+		>>I
	Pause / Step		Pause
	Prog. Memo.		TV/R





Original	Sustituto
	Rec
	Stop
	Vol +
	Vol -
	Text
	Subt
	Yellow
	Blue
	Dual
	Exit
	Shift + Power
	Shift + AV
	Shift + Ch +
	Shift + Ch -
	Shift + Vol +
	Shift + Vol -

Original	Sustituto

