



| Original | Sustituto               |
|----------|-------------------------|
| Power    | Power                   |
| Tv/Rad   | TV/Radio /              |
| Search/* | Shift + Red / Netflix / |
| Subtitle | Subtitle / EQ           |
| *        | Setup / OPT /           |
| Source   | AV / Input / RDS        |
| 1        | 1                       |
| 2        | 2                       |
| 3        | 3                       |
| 4        | 4                       |
| 5        | 5                       |
| 6        | 6                       |
| 7        | 7                       |
| 8        | 8                       |
| 9        | 9                       |
| List     | Smart / List            |
| 0        | 0                       |

| Original          | Sustituto                   |
|-------------------|-----------------------------|
| .../*             | Display / Media             |
| Vol+              | Vol+                        |
| FAV//Quic Acces/* | Fav / Marker / PC           |
| CH+               | CH+ / Page+                 |
| Vol-              | Vol-                        |
| Guide             | Guide / EPG / -/-           |
| CH-               | CH- / Page-                 |
| Mute              | Mute / Dimmer               |
| Text              | Text / Goto                 |
| Home              | Menu / Home                 |
| T.Opt.            | Shift + Setup / OPT / Tools |
| Back              | Back / Return               |
| Up                | Up                          |
| Exit              | Exit / Cancel / Clear       |
| Left              | Left                        |
| OK                | OK                          |
| Right             | Right                       |





|  | Original | Sustituto                   | Original | Sustituto |
|--|----------|-----------------------------|----------|-----------|
|  | AD/*     | Audio / Lang I/II           |          |           |
|  | Down     | Down                        |          |           |
|  | Q.Menu/* | D.Menu / Top                |          |           |
|  | Movies   | Picture / Format            |          |           |
|  | Rec/*    | Rec / Rec Mode              |          |           |
|  | Stop     | Stop / Hold                 |          |           |
|  | <<       | << / Tune-                  |          |           |
|  | Play     | Play / Slow                 |          |           |
|  | Pause    | Pause / Step / Freeze       |          |           |
|  | >>       | >> / Tune+                  |          |           |
|  | Red      | Red / Netflix / Search      |          |           |
|  | Green    | Green / APP / Repeat        |          |           |
|  | Yellow   | Yellow / YouTube / Repeat   |          |           |
|  | Blue     | Blue / Prime Video / Random |          |           |
|  |          |                             |          |           |
|  |          |                             |          |           |
|  |          |                             |          |           |
|  |          |                             |          |           |
|  |          |                             |          |           |
|  |          |                             |          |           |
|  |          |                             |          |           |
|  |          |                             |          |           |
|  |          |                             |          |           |
|  |          |                             |          |           |

