




















Original	Sustituto
	Power
	Mute
	1
	2
	3
	4
	5
	6
	7
	8
	9
	0
	TV/R
	Back
	Dual
	Menu
	Info

Original	Sustituto
	Guide
	Smart
	Exit
	Up
	Left
	Ok
	Right
	Down
	Ch -
	Ch +
	Vol -
	Vol +
	AV
	Red
	Green
	Text
	Yellow



