





















































































Original	Sustituto	Original	Sustituto
On/Off	 Power	OK Enter	 Ok
Audio Off	 Mute	Menu Right	 Right
Slow Down	 Ch -	Return	 Back
Stop	 Stop	Menu Down	 Down
Pause	 Pause	Volume+	 Vol +
Auto/Track	 Red	Progr.	 Sleep
Slow Up	 Ch +	Next	 >>
Subt.	 Subt	Volume-	 Vol -
Rep/A-B	 +  Shift + Text	Top Menu	 D. Menu
Title	 List	Prev.	 <<
DVD/TV	 Media	1	 1
Repeat/1/All	 Text	2	 2
Zoom	 +  Shift + Eject	3	 3
Menu	 Menu	4	 4
Menu Up	 Up	5	 5
Display	 +  Shift + Info	6	 6
Menu Left	 Left	7	 7







































Original	Sustituto	
8		8
9		9
Store		Green
Digest		Yellow
Random	 + 	Shift + Format
Play		Play
Game		Blue
+10		Guide
Np	 + 	Shift + List
Remain		Exit
Karaoke/Step	 + 	Shift + >>
Shuffle	 + 	Shift + TV/R
0		0
C/CH		Pre Ch
Record		Rec
Video		Options
Rewind		<<

Original	Sustituto	
ON/Off	 + 	Shift + Power
Mode		Smart
Key-	 + 	Shift + Left
Input Source		AV
3D		3D
F.Forward		>>
Play/Back	 + 	Shift + Play
Timer	 + 	Shift + AV
Open/Close		Eject
Resume	 + 	Shift + Pause
Audio	 + 	Shift + Dual
Key+	 + 	Shift + Right
Vocal/Assist	 + 	Shift + Vol +
Search		TV/R
Tone	 + 	Shift + Vol -
Info		Info
Angle		Format



Original	Sustituto	Original	Sustituto
Lang	 Dual		



Original	Sustituto	Original	Sustituto
On/Off	 Power	OK Enter	 Ok
Audio Off	 Mute	Menu Right	 Right
Slow Down	 Ch -	Progr.	 Sleep
Subt.	 Subt	Return	 Back
Auto/Track	 Red	Menu Down	 Down
Slow Up	 Ch +	Top Menu	 D. Menu
Rep/A-B	 +  Shift + Text	Volume+	 Vol +
Title	 List	Volume-	 Vol -
Stop	 Stop	1	 1
Pause	 Pause	2	 2
Repeat/1/All	 Text	Next	 >>
Zoom	 Eject	3	 3
DVD/TV	 AV	4	 4
Menu	 Menu	Prev.	 <<
Menu Up	 Up	5	 5
Display	 +  Shift + Info	6	 6
Menu Left	 Left	7	 7



Original	Sustituto	Original	Sustituto
Rewind	 <<	8	 8
Play	 Play	Audio	 +  Shift + Dual
Record	 Rec	Info	 Info
Np	 Green	9	 9
Angle	 Format	+10	 Guide
Video	 Smart	0	 0
Remain	 Blue	C/CH	 Pre Ch
Pbc	 Yellow	ON/Off	 +  Shift + Power
Syst.Preset	 Media	Key-	 +  Shift + Left
F.Forward	 >>	Auto Scan	 +  Shift + Ok
Setup	 Options	Key+	 +  Shift + Right
Timer	 +  Shift + AV	Echo+	 +  Shift + Ch +
3D	 3D	Echo-	 +  Shift + Ch -
Play/Back	 +  Shift + Play	Digest	 +  Shift + Guide
Shuffle	 +  Shift + TV/R		
Lang	 Dual		
Random	 +  Shift + Format		

