



















































Original	Sustituto	Original	Sustituto
 Power	 Power	 Left	 Left
 Open / Close	 Exit	 Enter	 Ok
 1	 1	 Right	 Right
 2	 2	 Down	 Down
 3	 3	 Menu	 Menu
 4	 4	 Audio / RL	 Dual
 5	 5	 OSD	 Info
 6	 6	 Zoom	 Eject
 7	 7	 Subtitle	 Subt
 8	 8	 DVD / USB	 Media
 9	 9	 Play / Pause	 Play
 0	 0	 Stop	 Stop
 Vol-	 Vol -	 Repeat	 Text
 Vol+	 Vol +	 Angle	 Format
 Setup	 Options	 <<	 <<
 Search	 TV/R	 >>	 >>
 Up	 Up	 I<<	 I<<

Original	Sustituto	Original	Sustituto
 MUTE	 MUTE	 SHIFT	 SHIFT
 TV	 TV	 DVD	 DVD
 SAT	 SAT	 AUX	 AUX
 PLAY MODE	 PLAY MODE	 REC MODE	 REC MODE
 Play	 Play	 Pause	 Pause
 Stop	 Stop	 >>	 >>
 <<	 <<	 SOUND	 SOUND
 AD	 AD	 SETTINGS	 SETTINGS
 LIST	 LIST	 DUAL	 DUAL
 SUBT	 SUBT	 OPT	 OPT
 PROG	 PROG	 PICTURE	 PICTURE
 ECO	 ECO	 3D	 3D
 SLEEP	 SLEEP	 TV/R	 TV/R
 FORMAT	 FORMAT	 TIMER	 TIMER
 E-MANUAL	 E-MANUAL	 ZOOM	 ZOOM
 REPEAT	 REPEAT	 AV	 AV
 D.MENU	 D.MENU	 TEXT	 TEXT
 TOP MENU	 TOP MENU	 MENU	 MENU
 DISPLAY	 DISPLAY	 INFO	 INFO
 MENU	 MENU	 OK	 OK
 RETURN	 RETURN	 BACK	 BACK
 CLEAR	 CLEAR	 EXIT	 EXIT
 HOME	 HOME	 SMART	 SMART
 +	 +	 APP	 APP
 -	 -	 MEDIA	 MEDIA
 1	 1	 2	 2
 2	 2	 3	 3
 3	 3	 4	 4
 4	 4	 5	 5
 5	 5	 6	 6
 6	 6	 7	 7
 7	 7	 8	 8
 8	 8	 9	 9
 9	 9	 0	 0
 0	 0	 FAV	 FAV
 GUIDE	 GUIDE	 PRE-CH	 PRE-CH
 A	 A	 B	 B
B	B	C	C
C	C	D	D
D	D	Mandis SHOP	Mandis SHOP
www.mandis.tv	www.mandis.tv		



