






































































Original	Sustituto	Original	Sustituto
	Power		Power
	FM		Smart
	AM		Media
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	10		0
	+10		Guide
	Sleep		Sleep
	Sound Mode		Dual
	FM Mode		TV/R
	S.A. Bass		Options
	Tape A		Red
	Tape B		Green
	Direction		Pre Ch
	Repeat		Text
	Pause		Pause
	CD Control		Yellow
	Play CD		Play
	Stop CD		Stop
	Rec Pause		Rec
	Volume+		Vol +
	Volume-		Vol -
	I<< CD		I<<
	<< CD		<<
	>>I CD		>>I
	>> CD		>>
	Play Tape		Shift + Play





Original	Sustituto	Original	Sustituto
 Stop Tape	 +  Shift + Stop	 2 CD	 +  Shift + 2
 Tape Control	 Blue	 3 CD	 +  Shift + 3
 AUX	 AV	 4 CD	 +  Shift + 4
 >> Tape	 +  Shift + >>	 5 CD	 +  Shift + 5
 << Tape	 +  Shift + <<	 6 CD	 +  Shift + 6
 Disc 1	 Subt	 7 CD	 +  Shift + 7
 Disc 2	 Format	 8 CD	 +  Shift + 8
 Disc 3	 Eject	 9 CD	 +  Shift + 9
 PTY/EON	 Menu	 10 CD	 +  Shift + 0
 Display Mode	 Info	 +10 CD	 +  Shift + Guide
 Select-	 Ch -		
 Select+	 Ch +		
 >> Tuning	 Up		
 << Tuning	 Down		
 << Tuning	 Left		
 >> Tuning	 Right		
 1 CD	 +  Shift + 1		

