















































































Original		Sustituto		Original		Sustituto	
	On/Standby		Power		Sleep		Sleep
	Open/Close		Eject		Bass/Treble		Options
	1		1		X-Bass		Dual
	2		2		Random		Subt
	3		3		<</></Tuning		<<
	4		4		>>/>>/Tuning		>>
	5		5		Folder		Text
	6		6		Demo/Dimmer		Info
	7		7		Preset Up		Up
	8		8		Preset Down		Down
	9		9		Enter		Ok
	0		0		Vol+		Vol +
	10+		Guide		Vol+		Right
	Back/Repeat		Back		Vol-		Vol -
	Memory		Smart		Vol-		Left
	Clear		Exit		Mute		Mute
	Clock/Timer		AV		CD		Yellow





Original		Sustituto		Original	Sustituto
	USB		Green		
	Tuner		Blue		
	Input/Audio/Line		Red		
	iPod		3D		
	(Tv Out)/Display		TV/R		
	Menu		Menu		
	Play/Pause iPod		Play		
	Display CD/USB		Ch +		
	Stop CD/USB		Stop		
	Play/Pause		Pause		
	ASPM RDS		D. Menu		
	PTY RDS		Format		
	Display RDS		Ch -		

