



Original	Sustituto
Power	Power
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
Vol+	Vol+
CH+	CH+ / Page+
Vol-	Vol-
Mute	Mute / Dimmer
CH-	CH- / Page-
Source	AV / Input / RDS

Original	Sustituto































Original	Sustituto
Power	Power
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
Menu	Menu / Home
<<	<< / Tune-
Play	Play / Slow
>>	>> / Tune+
Stop	Stop / Hold
Pause	Pause / Step / Freeze

Original	Sustituto
Red	Red / Netflix / Search
Up	Up
Left	Left
OK	OK
Right	Right
Exit	Exit / Cancel / Clear
Down	Down
i	Info / Angle
CH+	CH+ / Page+
CH-	CH- / Page-





Original	Sustituto
 Power	 Power
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Menu	 Menu / Home
 <<	 << / Tune-
 Play	 Play / Slow
 >>	 >> / Tune+
 Rec	 Rec / Rec Mode
 Stop	 Stop / Hold

Original	Sustituto
 Pause	 Pause / Step / Freeze
 Red	 Red / Netflix / Search
 Green	 Green / APP / Repeat
 Yellow	 Yellow / YouTube / Repeat
 Blue	 Blue / Prime Video / Random
 Media	 Display / Media
 Up	 Up
 Guide	 Guide / EPG / -/-
 Left	 Left
 OK/List	 OK
 OK/List	 +  Shift + Smart / List
 Right	 Right
 Exit	 Exit / Cancel / Clear
 Down	 Down
 Last	 Back / Return
 Vol+	 Vol+
 Info	 Info / Angle













Original	Sustituto
CH+	CH+ / Page+
Vol-	Vol-
Mute	Mute / Dimmer
CH-	CH- / Page-
I>	Shift + Play /
I<<	I<< / Preset-
>>I	>>I / Preset+
?	D.Menu / Top
Audio	Audio / Lang I/II
[...]	Subtitle / EQ
[=+]	Sound / Title
[≡I≡]	Smart / List
OPT+	Setup / OPT /
Edit	Fav / Marker / PC
Teletext	Text / Goto
Tv/Radio	TV/Radio /
Sleep	Sleep / Timer

Original	Sustituto
Source	AV / Input / RDS
Wide	Zoom / Size
V-Format	Picture / Format





Original	Sustituto
 Power	 Power
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 7	 7
 8	 8
 9	 9
 0	 0
 Menu	 Menu / Home
 <<	 << / Tune-
 >>	 >> / Tune+
 Up	 Up
 Guide	 Guide / EPG / -/--
 Left	 Left
 OK/List	 OK

Original	Sustituto
 OK/List	 Smart / List
 Right	 Right
 Exit	 Exit / Cancel / Clear
 Down	 Down
 Vol+	 Vol+
 Info	 Info / Angle
 CH+	 CH+ / Page+
 Vol-	 Vol-
 Mute	 Mute / Dimmer
 CH-	 CH- / Page-

