







































































Original	Sustituto	Original	Sustituto
 Power	 Power	 Info	 Info
 Mute	 Mute	 EPG	 Guide
 1	 1	 FAV	 Pre Ch
 2	 2	 Audio	 Dual
 3	 3	 Recall	 Back
 4	 4	 Menu	 Menu
 5	 5	 Exit	 Exit
 6	 6	 Up / CH+	 Up
 7	 7	 Up / CH+	 Ch +
 8	 8	 Down / CH-	 Down
 9	 9	 Down / CH-	 Ch -
 0	 0	 Right / Vol+	 Right
 Page-	 I<<	 Right / Vol+	 Vol +
 Page+	 >>I	 Left / Vol-	 Vol -
 Subtitle	 Subt	 Left / Vol-	 Left
 Teletext	 Text	 OK	 Ok
 Zoom	 Eject	 Red / Play/Pause	 Red





Original	Sustituto	Original	Sustituto
 Red / Play/Pause	 Play		
 Red / Play/Pause	 Pause		
 Green / TV/Radio	 Green		
 Green / TV/Radio	 TV/R		
 Yellow / Edit	 Yellow		
 Blue / Preview	 Blue		

