





































Original	Sustituto
 On	 Power
 Standby	 Shift + Power
 Input Selector V1	 1
 Input Selector V2	 4
 Input Selector V3	 7
 Input Selector Multi CH	 8
 Input Selector	 2
 Input Selector	 5
 Input Selector Tuner	 6
 Input Selector CD	 3
 Dimmer	 Shift + Mute / Dimmer
 Sleep	 Sleep / Timer
 CH/Disc+	 CH+ / Page+
 Vol+	 Vol+
 CH/Disc-	 CH- / Page-
 Vol-	 Vol-
 SP A/B	 Menu / Home

Original	Sustituto
 Up	 Up
 Muting	 Mute / Dimmer
 Left	 Left
 Enter	 OK
 Right	 Right
 Return	 Back / Return
 Down	 Down
 Setup	 Setup / OPT /
 Pause /<	 Pause / Step / Freeze
 Play	 Play / Slow
 Stop	 Stop / Hold
 << / Tune-	 << / Tune-
 >> / Tune+	 >> / Tune+
 I<<	 I<< / Preset-
 >>I	 >>I / Preset+
 List. Mode Stereo	 Red / Netflix / Search
 List. Mode	 Eject / Surround



Surround



Original	Sustituto
 List. Mode	 Green / APP / Repeat
 Listening Mode <	 Yellow / YouTube / Repeat
 Listening Mode >	 Blue / Prime Video / Random
 Test Tone	 Text / Goto
 CH Sel	 Info / Angle
 Level-	 Shift + Left
 Level+	 Shift + Right
 Display	 Display / Media
 L.Night	 Shift + Sleep / Timer
 Cine FLTR	 Picture / Format

Original	Sustituto







Original	Sustituto
 On	 Power
 Standby	 Shift + Power
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 +10	 Guide / EPG / -/--
 0	 0
 CLR	 Exit / Cancel / Clear
 CH/Disc+	 CH+ / Page+
 CH/Disc-	 CH- / Page-
 Top Menu	 D.Menu / Top

Original	Sustituto
 Up	 Up
 Menu	 Menu / Home
 Left	 Left
 Enter	 OK
 Right	 Right
 Return	 Back / Return
 Down	 Down
 Setup	 Setup / OPT /
 Pause	 Pause / Step / Freeze
 Play	 Play / Slow
 Stop	 Stop / Hold
 <<	 << / Tune-
 >>	 >> / Tune+
 I<<	 I<< / Preset-
 I>>	 I>> / Preset+
 Audio	 Audio / Lang I/II
 Subtitle	 Subtitle / EQ



