










Original	Sustituto
 POWER	 Power
 CH+	 Ch +
 CH-	 Ch -
 VOL+	 Vol +
 VOL-	 Vol -
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 MUTE	 Mute
 RTN.	 Back

Original	Sustituto
 ARC	 Smart
 APC	 Media
 UP	 Up
 LEFT	 Left
 OK	 Ok
 RIGHT	 Right
 DOWN	 Down
 MENU	 Menu
 EXIT	 Exit
 TELETEXT	 Text
 Index	 Play
 Clock / Subpage	 Pause
 Hold	 Stop
 Reveal	 Rec
 Cancel	 <<
 Size	 >>
 RED	 Red





Original	Sustituto	Original	Sustituto
GREEN	B Green		
YELLOW	C Yellow		
BLUE	D Blue		
SOUND	SOUND DUAL Dual		
SUB-TITLE	AD SUBT Subt		
GUIDE	GUIDE Guide		
SLEEP	SLEEP Sleep		
TV	SHIFT + A Shift + Red		
PC / HD	SHIFT + B Shift + Green		
VIDEO	SHIFT + C Shift + Yellow		
SCART	SHIFT + D Shift + Blue		

Original	Sustituto	Original	Sustituto

