





















































































Original	Sustituto	Original	Sustituto
 Power	 Power	 5	 5
 Eject	 Eject	 6	 6
 Monitor	 Subt	 7	 7
 Wide	 3D	 8	 8
 Counter Remain	 TV/R	 9	 9
 Slow	 Red	 0	 0
 X2	 Green	 -/--	 Guide
 I<< Index Search	 I<<	 Input Select	 Smart
 Index Search >>I	 >>I	 Prog+	 Ch +
 [i+]	 Info	 Prog-	 Ch -
 Clear	 Exit	 Timer	 Shift + AV
 SP/LP	 Format	 Menu	 Menu
 [->]	 AV	 Rec	 Rec
 1	 1	 Smart Search	 Options
 2	 2	 Pause	 Pause
 3	 3	 Up	 Up
 4	 4	 Down	 Down







































	Original	Sustituto	Original	Sustituto
	Stop			
	Right			
	>>			
	Left			
	<<			
	Play			
	OK			





Original	Sustituto
 Power	 Power
 Audio	 Dual
 Wide	 Format
 Counter Remain	 Smart
 []	 Subt
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 Display	 Info
 Tv/Video	 TV/R
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6

Original	Sustituto
 7	 7
 8	 8
 9	 9
 0	 0
 -/--	 Guide
 Prog+	 Ch +
 Prog-	 Ch -
 Vol+	 Vol +
 Vol-	 Vol -

