















































Original	Sustituto
 Power	 Power
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 TV	 TV/R
 Guide	 Guide
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute
 List	 List

Original	Sustituto
 P+	 Ch +
 P-	 Ch -
 Source	 AV
 APP	 Media
 History	 Options
 PRE-CH	 Pre Ch
 [i]	 Info
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 =	 Menu
 Home	 Smart
 O)/Lang	 Dual
 Back	 Back
 Subtitle	 Subt





Original	Sustituto
 Text	 Text
 Zoom	 Eject
 3D	 3D
 Sleep	 Sleep
 Rec	 Rec
 Play	 Play
 Pause	 Pause
 <<<	 <<<
 Stop	 Stop
 >>>	 >>>
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue

Original	Sustituto

