



Original	Sustituto
Bass Bost	Subtitle / EQ
Display	Display / Media
Power	Power
Tune Memory N. 1	1
Tune Memory N. 2	2
Tune Memory N. 3	3
Tune Memory N. 4	4
Tune Memory N. 5	5
Tune Memory N. 6	6
FM	Shift + 6
AM	Shift + 1
AUDIO IN	Shift + 2
CD	Shift + 3
USB	8
USB	Shift + 8
Tuner Memory	Smart / List
Clear	Exit / Cancel / Clear

Original	Sustituto
Up / Folder+	Up
Play Mode / Tuning Mode	Setup / OPT /
Repeat / FM Mode	Green / APP / Repeat
Left	Left
OK	OK
Right	Right
Volume+	Vol+
Return	Back / Return
Down / Folder-	Down
Timer Menu	Menu / Home
Volume-	Vol-
I<< / -	I<< / Preset-
Pause	Pause / Step / Freeze
>>I / +	>>I / Preset+
<<	<< / Tune-
Play	Play / Slow
>>	>> / Tune+



